

Marketing Bulletin

Fifth Wheels

New Part Numbering Standard

Explanation of new part numbering for standard-duty FW35, FW31, FW17, FWS1, FWS2 and FWAL Fifth Wheel assemblies

DECEMBER 2010

Introduction

SAF-HOLLAND has introduced a new fifth wheel assembly part number standard. The new part numbering covers the following standard-duty fifth wheel assemblies: FW35, FW31, FW17, FWS1, FWS2 and FWAL. Both sliding and stationary mounting styles are also listed in detail with corresponding number codes.

NOTE: New part numbering standard does not apply to Extra Capacity, Fully Oscillating, Terminal Tractor, Elevating, Light Commercial, No-Tilt, Kompensator Fifth Wheels, or ILS Sliders with 10" height or slide travels greater than 48". Contact SAF-HOLLAND Customer Service at 1-888-396-6501 for all other fifth wheel models and mounting styles.

Use the part number breakdown on the inside of this document to determine your exact fifth wheel assembly part numbers.

Now ordering your Holland fifth wheel assembly will be easier and more accurate than ever before. If you have questions regarding your selection, SAF-HOLLAND Customer Service Representatives are available at 1-888-396-6501 to answer any questions you may have.





SAF-HOLLAND Group


Fifth Wheel Part Numbering Standard

For FW35, FW31, FW17, FWS1, FWS2 & FWAL

To Determine Your Assembly Part Number:

1. Choose the Fifth Wheel Top Plate suitable for your application -
Contact Fifth Wheel Application Engineering at 1-888-396-6501 if you have questions or to confirm your model selection
2. Determine your Mounting Bracket Style
3. Specify your required Mounting Height
4. Select your appropriate Travel
5. Determine your Chassis Frame Width (If Applicable)
6. Select your Release Handle - Left-Hand or Right-Hand Pull
7. Specify any additional Options (If Desired)
8. With your full assembly number established, contact Customer Service at 1-888-396-6501 to order your new fifth wheel assembly

NOTE: New part numbering standard does not apply to Extra Capacity, Fully Oscillating, Terminal Tractor, Elevating, Light Commercial, No-Tilt, Kompensator Fifth Wheels, or ILS Sliders with 10" height or slide travels greater than 48". Contact SAF-HOLLAND Customer Service at 1-888-396-6501 for all other fifth wheel models and mounting styles.



FIFTH WHEEL TOP PLATE		
NO.	DESCRIPTION	
35	FW 35 Series	
31	FW31 Series NoLube	
17	FW17 Series	
S1	Simplex FWS1 Series	
S2	Simplex FWS2 Series	
AL	Aluminum	

MOUNTING BRACKET STYLE			
SLIDER		STATIONARY	
NO.	DESCRIPTION	NO.	DESCRIPTION
A	Outboard (1 pc. Tie-Bar) 	Z	Plate Mount (Formerly 788X)
B	Inboard - Serrated (3 pc. Tie-Bar) 	Y	Foot Mount (Formerly 780X)
C	Inboard - Straight (3 pc. Tie-Bar) 	X	Bracket - Casting Only (Formerly 782X)
F	Outboard (1 pc. Tie-Bar) (DTNA Only - Same as "A" Style) 	W	Bracket w/ 4" Vertical Leg Angle (Formerly 781X)
G	Outboard (3 pc. Tie-Bar) 	V	Bracket w/ 5" Vertical Leg Angle

Examples:

Old Part No: FW35-7002X3L11
(Slider) FW35 Top Plate, Inboard Mount,
 8" Height, 24" Travel, Left-Hand Release,
 Weightsaver Cut-Out Option

New Part No: FW35B824XL00
(Slider) FW35 Top Plate, Inboard Serrated Mount,
 8" Height, 24" Travel, Left-Hand Release,
 No Additional Options

Old Part No: 10669075
(Stationary) Simplex SE Top Plate,
 Bracket Casting Only Mount,
 7" Height, Touch-Loc Air Release

New Part No: FWS1X700XL80
(Stationary) Simplex S1 (SE) Top Plate,
 Bracket-Casting Only Mount, 7" Height,
 Left- Hand Release, Air Release Top Plate



HEIGHT* (Approx.)	
NO.	DESCRIPTION
6	6.0" (Stat. Only)
7	7.0
8	8.0"
9	9.0"

* Not all height selections are available for all top plates or mounting systems

TRAVEL	
NO.	DESCRIPTION
00	Stationary
12	12.0" Sliding
24	24.0" Sliding
36	36.0" Sliding
48	48.0" Sliding

FRAME WIDTH	
NO.	DESCRIPTION
X	Outboard Slider
X	Inboard Slider (w/o Angles)
X	Stationary (w/o Angles)
A	33.25"
B	33.38"
C	33.50"
D	33.62"
E	33.75"
F	33.88"
G	34.00"
H	34.12"
J	34.25"
K	34.38"
L	34.50"


RELEASE HANDLE	
NO.	DESCRIPTION
L	Left-Hand (Road-Side)
R	Right-Hand (Curb-Side)

OPTION CODE**	
NO.	DESCRIPTION
00	No Option
02	Manual Secondary Lock
24	Drilled & Tapped for Auto Lube
28	Dolly Release Handle
80	Air Release Top Plate
EL	Electronic Lock Indicator (ELI)
FR	Forward Biased Release Handle

** Not all options available on every top plate. Multiple option combinations are available.

MOUNTING HEIGHT

(Top of Fifth Wheel Top Plate to Top of Vehicle Frame Rails)



NOTE: For further details on option availability and specifying multiple option combinations, contact SAF-HOLLAND Customer Service at 1-888-396-6501



From fifth wheel rebuild kits to suspension bushing repair kits, SAF-HOLLAND Original Parts are the same quality components used in the original component assembly. SAF-HOLLAND Original Parts are tested and designed to provide maximum performance and durability. Will-fits, look-alikes or, worse yet, counterfeit parts will only limit the performance potential and could possibly void SAF-HOLLAND's warranty.

Always be sure to spec SAF-HOLLAND Original Parts when servicing your SAF-HOLLAND product.

SAF-HOLLAND USA • 888.396.6501 • Fax 800.356.3929
www.safholland.us

SAF-HOLLAND CANADA • 519.537.3494 • Fax 800.565.7753
WESTERN CANADA • 604.574.7491 • Fax 604.574.0244
www.safholland.ca

SAF-HOLLAND MEXICO • 52.1.55.5456.8641 • Fax 52.55.58162230
www.safholland.com.mx

info@safholland.com